

Table of Contents

INTRODUCTION TO THE SCPI LANGUAGE	1
COMMAND SYNTAX	1
SYNTAX RULES	1
COMMAND ABBREVIATION	2
CONTACT US	3
THIRD-PARTY API	3
*COMMON COMMANDS.....	1
*ADC?	1
*AUTOSET	1
*LDM?	1
*RDM?	2
*RUNSTOP	2
*IDN?	3
*RST	3
:MEASURE COMMAND SUBSYSTEM	4
:MEASURE:SOURCE	4
:MEASURE:ADD	4
:MEASURE:DELETE.....	5
:MEASURE:PERIOD?	6
:MEASURE:FREQUENCY?	6
:MEASURE:AVERAGE?	7
:MEASURE:MAX?	8
:MEASURE:MIN?	8
:MEASURE:VTOP?.....	9
:MEASURE:VBASE?	10
:MEASURE:VAMP?	10
:MEASURE:PKPK?	11
:MEASURE:CYCRMS?	12
:MEASURE:RTIME?	12
:MEASURE:FTIME?	13
:MEASURE:PDUTY?	13
:MEASURE:NDUTY?	14
:MEASURE:PWIDTH?	15
:MEASURE:NWIDTH?	15
:MEASURE:OVERSHOOT?	16
:MEASURE:PRESHOOT?	17
:MEASURE:RDELAY?	17
:MEASURE:FDELAY?	18
:MEASURE:RECVAMP?	19
:ACQUIRE COMMAND SUBSYSTEM.....	19
:ACQUIRE:TYPE	19
:ACQUIRE:AVERAGE<COUNT>	20
:ACQUIRE:MDEPTH<MDEP>	20
:TIMEBASE COMMAND SUBSYSTEM.....	21
:TIMEBASE:SCALE	21
:TIMEBASE:HOFFSET	22
:FFT COMMAND SUBSYSTEM	22
:FFT:DISPLAY <BOOL>	22

:FFT:FREQBASE<HZ>	23
:FFT:SOURCE<SOURCE>	24
:FFT:FORMAT VRMS<VRMS_SCALE>	24
:FFT:FORMAT DB <DB_SCALE>	25
:FFT:WINDOW<ITEM>	25
:FFT:ZONE<FACTOR>	26
:CHANNEL COMMAND SUBSYSTEM.....	26
:CHANNEL:DISPLAY	26
:CHANNEL:COUPLING	27
:CHANNEL:PROBE	27
:CHANNEL:SCALE	28
:CHANNEL:OFFSET	29
:CHANNEL:HARDFREQ?	29
:CHANNEL:INVERSE	30
:LANCOMMAND SUBSYSTEM	30
:LAN:IPADDRESS	30
:LAN:PORT	31
:LAN:GATEWAY	31
:LAN:SMASK	32
:LAN:RESTART	32
:TRIGGERCOMMAND SUBSYSTEM	33
:TRIGGER:TYPE<TYPE>	33
:TRIGGER:MODE<MODE>	33
:TRIGGER:SINGLE<SMODE>	34
:TRIGGER:ALT <AMODE>	34
:TRIGGER:SINGLE:EDGE	35
:TRIGger:SINGLE:EDGE:SOURce	35
:TRIGger:SINGLE:EDGE:SLOPe	35
:TRIGger:SINGLE:EDGE:LEVel.....	36
:TRIGGER:SINGLE:VIDEO	36
:TRIGger:SINGLE:VIDeo:SOURce.....	36
:TRIGger:SINGLE:VIDeo:MODU	37
:TRIGger:SINGLE:VIDeo:SYNC	37
:TRIGger:SINGLE:VIDeo:LNUM	38
:TRIGGER:ALT:EDGE	38
:TRIGger:ALT:EDGE:SOURce	38
:TRIGger:ALT:EDGE:SLOPe	39
:TRIGger:ALT:EDGE:LEVel.....	39
:TRIGGER:ALT:VIDEO	40
:TRIGger:ALT:VIDeo:SOURce	40
:TRIGger:ALT:VIDeo:MODU	41
:TRIGger:ALT:VIDeo:SYNC	41
:TRIGger:ALT:VIDeo:LNUM	42

History version	Modified content	Modifier	Time
V1.1	+) *RST、:CHANnel:INVerse、history version	Richard	2014.0809
V1.2	+) *LDM?、*RDM?、*RUNStop, modification description	Richard	2014.1114 2014.1126 2014.1127
V1.3	modification description,and thank you for translation by 谢招荣	谢招荣	2014.1210

Introduction to the SCPI Language

Command Syntax

The command systems of VDS series present a hierarchy structure (tree system) and each command consists of a “Root” keyword and one or multiple sub-keywords. Command line always begins with colon “:”, the keywords are separated by “:” and are followed by the parameter settings available, “?” is added at the end of the command string to indicate query and the command and parameter are separated by “space”.

For example,

:TRIGger:SINGle:EDGE:SOURce <source>

:TRIGger:SINGle:EDGE:SOURce?

TRIGger is the root keyword of the command, SINGle, EDGE and SOURce are the second-level, third-level keywords and the fourth-level respectively. Command line always begins with colon “:”, all the keywords are separated by “:”. < source > denotes the parameter that users can set. “?” denotes query; the command :TRIGger:SINGle:EDGE:SOURce and parameter are separated by “space”.

Syntax Rules

SCPI language itself defines a group of sub-system keywords, and at the same time allows users to add or reduce keywords. Those keywords can be some meaningful English words and are easy to remember, which are called mnemonics. Mnemonic has long and short types. The short are the abbreviation of the long. Special characters are used to separate keywords, data and sentences.

➤ Rule to format mnemonics:

- 1) If the letter number of an English word is less than or equal to 4, then the word itself can be the mnemonic.(such as “Free” can be “FREE”)
- 2) If the letter number of an English word exceeds 4, then the first four letters will be the mnemonic.(such as “Frequency” can be “FREQ”)
- 3) If the forth letter is vowel, then mnemonic uses the former three letters. Vowels consists of a, e, i, o, and u.(such as “Power” can be “POW”)
- 4) If it is not a word but a sentence, then use the first letters of the former words and the whole of the last word. (such as “Input Voltage “ can be “IVOLTage”)

➤ Usage of symbols

- 1) Space

The space is used to separate command and parameter.

- 2) Colon :

If the colon is in front of the first character, it means the following is Root Command. When the colon is set between two keywords, then it means moving from the current level to the next level.

- 3) asterisk*

The commands start with asterisk are named Common Command, which is used to execute IEEE488.2 common commands.

- 4) Braces {}

The parameters enclosed in the braces are optional and are usually separated by the vertical bar “|”. When using this command, one of the parameters must be selected.

- 5) Vertical Bar |

The vertical bar is used to separate multiple parameters and one of the parameters must be selected when using the command.

6) Triangle Brackets < >

The parameter enclosed in the triangle brackets must be replaced by an effective value.

7) Square Brackets []

The parameter enclosed in the square brackets can be replaced by effective value or ignored. If not designated value for the parameter, default value will be used.

➤ **Parameter Type**

1) **Discrete**

The parameter should be one of the values listed. For example,

:MEASure:SOURce <source>

:MEASure:SOURce?

wherein,

<source> can be set to CH1|CH2

The query returns the abbreviated format: “CH1” 、 “CH2”

2) **Integer**

Unless otherwise noted, the parameter can be any integer (NR1 format) within the effective value range. Note that, do not set the parameter to a decimal, otherwise errors will occur.

For example,

:CHANnel<n>:OFFSet <offset>

:CHANnel<n>:OFFSet?

wherein,

<n> can be set to 1 or 2, represents CH1 or CH2.

<offset> can be set to any integer between -250 and 250.

The query returns any integer between -250 and 250.

3) **Bool**

The parameter could be "OFF", "ON".

For example,

:CHANnel1:DISPlay <bool>

:CHANnel1:DISPlay?

wherein,

<bool> can be set to {OFF|ON}

The query returns “OFF” or “ON” .

Command Abbreviation

Each SCPI command can be written mixed with uppercase and lowercase according to the syntax rules, and the capital letter part is just the abbreviation of the command. If abbreviation is used, all the capital letters in the command must be written completely. For parameters with units, please refer to the detail parameter specifications in the sub-system.

Example 1:

:ACQuire:TYPE SAMPlE

Abbreviation Below:

:ACQ:TYPE SAMP

Example 2:

:CHANnel1:SCALe 1v

Abbreviation Below:

:CHAN1:SCAL 1v

Contact us

If you have any problem or requirement when using our products, please contact OWON.

Service & Support Hotline: **4006 909 365**

Website:

<http://www.owon.com.hk/>

Third-party API

The SCPI protocol of this product is based on USB port and LAN communication. After opening the pc software, SCPI protocol server is automatically activated. A client is provided in the sample Application, which can communicate with devices by sending SCPI commands to device and receiving feedback or data from device. Even more important, the code for client is easy, binded with server IP and port, and use network sockets to communicate. The client effect can be easily realised in the third-party software development.

*Common Commands

*ADC?

Syntax

*ADC? [n]

Description

Acquire ADC data on the screen for the designated channel.

Parameter

Name	Type	Range	Default Value
[n]	Discrete	{CH1 CH2 CH3 CH4}	CH1

Explanation

For one-channel oscilloscope, the range is {1}.

For two-channel oscilloscope, the range is {1|2}.

For four-channel oscilloscope, the range is {1|2|3|4}.

Return Format

The query returns specific ADC data.

Example

The query below returns 50,50,50,50,50,50,50,50,50,50,...

*ADC? CH1

*AUToset

Automatically set the device to best status.

Return Format

" success" or "failed" .

*LDM?

Syntax

*LDM? [address]

Description

Acquire full sample data and save it to local server. [Address] indicates hard disk storage address of the server computer. LDM is abbreviation of Local Deep Memory Data.

Parameter

Name	Type	Range	Default Value
[address]	string	-----	Server installation directory

Explanation

[Address] is the default at server installation directory with default file name without input,
format: current system date. bin.

Return Format

Return "success" or "failed", and return Saved @ "specific address"

Example

The command below will acquire and save full deep memory data to hard disk D of server computer.

*LDM? D:\

RDM?*Syntax**

*RDM?

Description

Acquire full sample data and save it to remote client. Usually on the same level as client or upper level directory, the directory address can be designated by developer, file name is dm.bin. RDM is abbreviation of Remote Deep Memory Data.

Return Format

Return "success" or "failed" .

Example

The command below acquire full deep memory sample data and send to client.

*RDM?

RUNStop*Syntax**

*RUNStop

Description

Send this command to control Run and Stop.

Return Format

Return the status. Example: Set Run or Set Stop.

Example

If it is in run status, the command below will set it to stop status.

*RUNStop

If it is in stop status, the command below will set it to run status.

*RUNStop

***IDN?**

Return the ID character string of the instrument

Description

The query returns the ID character string of the instrument.

Return Format

OWON,<model>,<serial number>,X.XX.XX
<model>: the model number of the instrument.
<serial number>: the serial number of the instrument.
X.XX.XX: the software version of the instrument.

Example

OWON, VDS3104, VDS31041418200, V1.0.4

***RST**

Restore the instrument to its default value.

Return Format

"success" or "failed".

:MEASure Command Subsystem

:MEASure:SOURce

Syntax

:MEASure:SOURce <source>

:MEASure:SOURce?

Description

Select the measurement source of the 22 measurement parameters.

Parameter

Name	Type	Range	Default Value
<source>	Discrete	{CH1 CH2 CH3 CH4}	CH1

Explanation

This oscilloscope can measure 22 parameters.

You need to specify one measurement source for the following 20 parameters:

10 Voltage Measurement Items: Maximum, Minimum, Peak-Peak, Top, Bottom, Amplitude, Average, RMS, Overshoot and Preshoot.

12 Time Measurement Items: Period, Frequency, Rise Time, Fall Time, Positive Pulse Width, Negative Pulse Width, Positive Duty Cycle, Negative Duty Cycle, Delay 1→2, Delay 1→2, Delay 3→4, Delay 3→4.

Return Format

The query returns one or more than one channel among "CH1", "CH2", "CH3" and "CH4".

Example

The command below sets CH1 as the measurement source.

:MEASure:SOURce CH1

The query below returns "CH1".

:MEASure:SOURce?

:MEASure:ADD

Syntax

:MEASure:ADD <item>

Description

Add any one of or all of the 22 measurement items.

Parameter

Name	Type	Range	Default Value
<item>	Discrete	{ PERiod FREQuency AVERage MAX MIN VTOP VBASE VAMP PKPK CYCRms RTime FTime PDUTy NDUTy PWIDth NWIDth OVERshoot PRESshoot RDELay FDELay }	----

The sequence of measurement items which corresponding to the ITEM above is as below:
 Period, Frequency, Average, Maximum, Minimum, Top, Bottom, Amplitude, Peak-Peak, RMS, Rise Time, Fall Time, Positive Duty Cycle, Negative Duty Cycle, Positive Pulse Width, Negative Pulse Width, Overshoot, Preshoot, Delay 1→2 $\frac{f}{T}$, Delay 1→2 $\frac{T}{f}$, Delay 3→4 $\frac{f}{T}$, Delay 3→4 $\frac{T}{f}$.

Explanation

This oscilloscope can measure 22 parameters.

You need to specify one measurement source for the following 20 parameters:

10 Voltage Measurement Items: Maximum, Minimum, Peak-Peak, Top, Bottom, Amplitude, Average, RMS, Overshoot and Preshoot.

12 Time Measurement Items: Period, Frequency, Rise Time, Fall Time, Positive Pulse Width, Negative Pulse Width, Positive Duty Cycle, Negative Duty Cycle, Delay 1→2 $\frac{f}{T}$, Delay 1→2 $\frac{T}{f}$, Delay 3→4 $\frac{f}{T}$, Delay 3→4 $\frac{T}{f}$.

Example

The command below adds the measurement item PERiod.

:MEASure:ADD PERiod

:MEASure:DElete

Syntax

:MEASure:DElete <item>

Description

Delete specified or all measurement items.

Parameter

Name	Type	Range	Default Value
<item>	Discrete	{ PERiod FREQuency AVERage MAX MIN VTOP VBASE VAMP PKPK CYCRms RTime FTime PDUTy NDUTy PWIDth NWIDth OVERshoot PREShoot RDELay FDELay }	-----

Explanation

This oscilloscope can measure 22 parameters.

You need to specify one measurement source for the following 22 parameters:

10 Voltage Measurement Items: Maximum, Minimum, Peak-Peak, Top, Bottom, Amplitude, Average, RMS, Overshoot and Preshoot.

12 Time Measurement Items: Period, Frequency, Rise Time, Fall Time, Positive Pulse Width, Negative Pulse Width, Positive Duty Cycle, Negative Duty Cycle, Delay 1→2 $\frac{f}{T}$, Delay 1→2 $\frac{T}{f}$, Delay 3→4 $\frac{f}{T}$, Delay 3→4 $\frac{T}{f}$.

Note:

1. When sending the command :MEASure:DElete ALL, all the measurements will be deleted and the checked channel will be canceled.

Example

The command below deletes MAX measurement.

:MEASure:DElete MAX

:MEASure:PERiod?

Syntax

:MEASure[n]:PERiod?

Description

Query the measurement value of the period of the current selected channel. The default unit is s.

Parameter

Name	Type	Range	Default Value
[n]	Discrete	{1 2 3 4}	1

Explanation

Parameter[n] indicates channel, it can be ignored, and the default channel is the current selected one, The default value could be change.If [n] is replaced with a value, then the query returns measurement value of channel [n].

If no specified unit, then default unit will be Volt(v) for voltage. And default unit for time is Sec(s). Default unit for frequency is Hz. Default unit for percent is decimal form, for example 88% is 0.88.

For one-channel oscilloscope, the Range is { 1 }.

For two-channel oscilloscope, the Range is {1|2}.

For four-channel oscilloscope, the Range is {1|2|3|4}.

Return format

The query returns the measurement result in character string.

Example

The query below returns the measurement value of the period of current channel.

:MEASure:PERiod?

:MEASure:FREQuency?

Syntax

:MEASure[n]:FREQuency?

Description

Query the measurement value of the period of the current selected channel. The default unit is Hz.

Parameter

Name	Type	Range	Default Value
[n]	Discrete	{1 2 3 4}	1

Explanation

Parameter[n] indicates channel, it can be ignored, and the default channel is the current selected one, The default value could be change.If [n] is replaced with a value, then the query returns measurement value of channel [n].

If no specified unit, then default unit will be Volt(v) for voltage. And default unit for time is Sec(s). Default unit for frequency is Hz. Default unit for percent is decimal form, for example 88% is 0.88.

For one-channel oscilloscope, the Range is { 1 }.

For two-channel oscilloscope, the Range is {1|2}.

For four-channel oscilloscope, the Range is {1|2|3|4}.

Return format

The query returns the measurement result in character string.

Example

The query below returns the measurement value of the frequency of current channel.

:MEASure:FREQuency?

:MEASure:AVERage?

Syntax

:MEASure[n]:AVERage?

Description

Query the measurement value of the average of the current selected channel. Unit depends on current unit of specified channel.

Parameter

Name	Type	Range	Default Value
[n]	Discrete	{1 2 3 4}	1

Explanation

Parameter[n] indicates channel, it can be ignored, and the default channel is the current selected one, The default value could be change.If [n] is replaced with a value, then the query returns measurement value of channel [n].

If no specified unit, then default unit will be Volt(v) for voltage. And default unit for time is Sec(s). Default unit for frequency is Hz. Default unit for percent is decimal form, for example 88% is 0.88.

For one-channel oscilloscope, the Range is { 1 }.

For two-channel oscilloscope, the Range is {1|2}.

For four-channel oscilloscope, the Range is {1|2|3|4}.

Return format

The query returns the measurement result in character string.

Example

The query below returns the measurement value of the average of current channel.

:MEASure:AVERage?

:MEASure:MAX?

Syntax

:MEASure[n]:MAX?

Description

Query the measurement value of the max of the current selected channel. Unit depends on current unit of specified channel.

Parameter

Name	Type	Range	Default Value
[n]	Discrete	{1 2 3 4}	1

Explanation

Parameter[n] indicates channel, it can be ignored, and the default channel is the current selected one, The default value could be change.If [n] is replaced with a value, then the query returns measurement value of channel [n].

If no specified unit, then default unit will be Volt(v) for voltage. And default unit for time is Sec(s). Default unit for frequency is Hz. Default unit for percent is decimal form, for example 88% is 0.88.

For one-channel oscilloscope, the Range is { 1 }.

For two-channel oscilloscope, the Range is {1|2}.

For four-channel oscilloscope, the Range is {1|2|3|4}.

Return format

The query returns the measurement result in character string.

Example

The query below returns the measurement value of the max of current channel.

:MEASure:MAX?

:MEASure:MIN?

Syntax

:MEASure[n]:MIN?

Description

Query the measurement value of the min of the current selected channel. Unit depends on current unit of specified channel.

Parameter

Name	Type	Range	Default Value
[n]	Discrete	{1 2 3 4}	1

Explanation

Parameter[n] indicates channel, it can be ignored, and the default channel is the current selected one, The default value could be change.If [n] is replaced with a value, then the query returns measurement value of channel [n].

If no specified unit, then default unit will be Volt(v) for voltage. And default unit for time is Sec(s). Default unit for frequency is Hz. Default unit for percent is decimal form, for example 88% is 0.88.

For one-channel oscilloscope, the Range is { 1 }.

For two-channel oscilloscope, the Range is {1|2}.

For four-channel oscilloscope, the Range is {1|2|3|4}.

Return format

The query returns the measurement result in character string.

Example

The query below returns the measurement value of the Min of current channel.

:MEASure:MIN?

:MEASure:VTOP?

Syntax

:MEASure[n]:TOP?

Description

Query the measurement value of the top of the current selected channel. Unit depends on current unit of specified channel.

Parameter

Name	Type	Range	Default Value
[n]	Discrete	{1 2 3 4}	1

Explanation

Parameter[n] indicates channel, it can be ignored, and the default channel is the current selected one, The default value could be change.If [n] is replaced with a value, then the query returns measurement value of channel [n].

If no specified unit, then default unit will be Volt(v) for voltage. And default unit for time is Sec(s). Default unit for frequency is Hz. Default unit for percent is decimal form, for example 88% is 0.88.

For one-channel oscilloscope, the Range is { 1 }.

For two-channel oscilloscope, the Range is {1|2}.

For four-channel oscilloscope, the Range is {1|2|3|4}.

Return format

The query returns the measurement result in character string.

Example

The query below returns the measurement value of the top of current channel.

:MEASure:TOP?

:MEASure:VBASe?

Syntax

:MEASure[n]: VBASe?

Description

Query the measurement value of the Vbase of the current selected channel. Unit depends on current unit of specified channel.

Parameter

Name	Type	Range	Default Value
[n]	Discrete	{1 2 3 4}	1

Explanation

Parameter[n] indicates channel, it can be ignored, and the default channel is the current selected one, The default value could be change.If [n] is replaced with a value, then the query returns measurement value of channel [n].

If no specified unit, then default unit will be Volt(v) for voltage. And default unit for time is Sec(s). Default unit for frequency is Hz. Default unit for percent is decimal form, for example 88% is 0.88.

For one-channel oscilloscope, the Range is { 1 }.

For two-channel oscilloscope, the Range is {1|2}.

For four-channel oscilloscope, the Range is {1|2|3|4}.

Return format

The query returns the measurement result in character string.

Example

The query below returns the measurement value of the Vbase of current channel.

:MEASure:VBASe?

:MEASure:VAMP?

Syntax

:MEASure[n]: VAMP?

Description

Query the measurement value of the Vamp of the current selected channel. Unit depends on current unit of specified channel.

Parameter

Name	Type	Range	Default Value
[n]	Discrete	{1 2 3 4}	1

Explanation

Parameter[n] indicates channel, it can be ignored, and the default channel is the current selected one, The default value could be change.If [n] is replaced with a value, then the query returns measurement value of channel [n].

If no specified unit, then default unit will be Volt(v) for voltage. And default unit for time is Sec(s). Default unit for frequency is Hz. Default unit for percent is decimal form, for example 88% is 0.88.

For one-channel oscilloscope, the Range is { 1 }.

For two-channel oscilloscope, the Range is {1|2}.

For four-channel oscilloscope, the Range is {1|2|3|4}.

Return format

The query returns the measurement result in character string.

Example

The query below returns the measurement value of the Vamp of current channel.

:MEASure:VAMP?

:MEASure:PKPK?

Syntax

:MEASure[n]: PKPK?

Description

Query the measurement value of the PKPK of the current selected channel. Unit depends on current unit of specified channel.

Parameter

Name	Type	Range	Default Value
[n]	Discrete	{1 2 3 4}	1

Explanation

Parameter[n] indicates channel, it can be ignored, and the default channel is the current selected one, The default value could be change.If [n] is replaced with a value, then the query returns measurement value of channel [n].

If no specified unit, then default unit will be Volt(v) for voltage. And default unit for time is Sec(s). Default unit for frequency is Hz. Default unit for percent is decimal form, for example 88% is 0.88.

For one-channel oscilloscope, the Range is { 1 }.

For two-channel oscilloscope, the Range is {1|2}.

For four-channel oscilloscope, the Range is {1|2|3|4}.

Return format

The query returns the measurement result in character string.

Example

The query below returns the measurement value of the PKPK of current channel.

:MEASure:PKPK?

:MEASure:CYCRms?

Syntax

:MEASure[n]: CYCRms?

Description

Query the measurement value of the CYCRms of the current selected channel. Unit depends on current unit of specified channel.

Parameter

Name	Type	Range	Default Value
[n]	Discrete	{1 2 3 4}	1

Explanation

Parameter[n] indicates channel, it can be ignored, and the default channel is the current selected one, The default value could be change.If [n] is replaced with a value, then the query returns measurement value of channel [n].

If no specified unit, then default unit will be Volt(v) for voltage. And default unit for time is Sec(s). Default unit for frequency is Hz. Default unit for percent is decimal form, for example 88% is 0.88.

For one-channel oscilloscope, the Range is { 1 }.

For two-channel oscilloscope, the Range is {1|2}.

For four-channel oscilloscope, the Range is {1|2|3|4}.

Return format

The query returns the measurement result in character string.

Example

The query below returns the measurement value of the CYCRms of current channel.

:MEASure:CYCRms?

:MEASure:RTIME?

Syntax

:MEASure[n]: RTIME?

Description

Query the measurement value of the RTime of the current selected channel. Unit is Sec(s).

Parameter

Name	Type	Range	Default Value
[n]	Discrete	{1 2 3 4}	1

Explanation

Parameter[n] indicates channel, it can be ignored, and the default channel is the current selected one, The default value could be change.If [n] is replaced with a value, then the query

returns measurement value of channel [n].

If no specified unit, then default unit will be Volt(v) for voltage. And default unit for time is Sec(s). Default unit for frequency is Hz. Default unit for percent is decimal form, for example 88% is 0.88.

For one-channel oscilloscope, the Range is { 1 }.

For two-channel oscilloscope, the Range is {1|2}.

For four-channel oscilloscope, the Range is {1|2|3|4}.

Return format

The query returns the measurement result in character string.

Example

The query below returns the measurement value of the RTime of current channel.

:MEASure:RTime?

:MEASure:FTIME?

Syntax

:MEASure[n]: FTIME?

Description

Query the measurement value of the FTime of the current selected channel. Unit is Sec(s).

Parameter

Name	Type	Range	Default Value
[n]	Discrete	{1 2 3 4}	1

Explanation

Parameter[n] indicates channel, it can be ignored, and the default channel is the current selected one, The default value could be change.If [n] is replaced with a value, then the query returns measurement value of channel [n].

If no specified unit, then default unit will be Volt(v) for voltage. And default unit for time is Sec(s). Default unit for frequency is Hz. Default unit for percent is decimal form, for example 88% is 0.88.

For one-channel oscilloscope, the Range is { 1 }.

For two-channel oscilloscope, the Range is {1|2}.

For four-channel oscilloscope, the Range is {1|2|3|4}.

Return format

The query returns the measurement result in character string.

Example

The query below returns the measurement value of the FTime of current channel.

:MEASure:FTime?

:MEASure:PDUTy?

Syntax

:MEASure[n]: PDUTy?

Description

Query the measurement value of the PDUTy of the current selected channel.

Parameter

Name	Type	Range	Default Value
[n]	Discrete	{1 2 3 4}	1

Explanation

Parameter[n] indicates channel, it can be ignored, and the default channel is the current selected one, The default value could be change.If [n] is replaced with a value, then the query returns measurement value of channel [n].

If no specified unit, then default unit will be Volt(v) for voltage. And default unit for time is Sec(s). Default unit for frequency is Hz. Default unit for percent is decimal form, for example 88% is 0.88.

For one-channel oscilloscope, the Range is { 1 }.

For two-channel oscilloscope, the Range is {1|2}.

For four-channel oscilloscope, the Range is {1|2|3|4}.

Return format

The query returns the measurement result in character string.

Example

The query below returns the measurement value of the PDUTy of current channel.

:MEASure:PDUTy?

:MEASure:NDUTy?

Syntax

:MEASure[n]: NDUTy?

Description

Query the measurement value of the NDUTy of the current selected channel.

Parameter

Name	Type	Range	Default Value
[n]	Discrete	{1 2 3 4}	1

Explanation

Parameter[n] indicates channel, it can be ignored, and the default channel is the current selected one, The default value could be change.If [n] is replaced with a value, then the query returns measurement value of channel [n].

If no specified unit, then default unit will be Volt(v) for voltage. And default unit for time is Sec(s). Default unit for frequency is Hz. Default unit for percent is decimal form, for example 88% is 0.88.

For one-channel oscilloscope, the Range is { 1 }.

For two-channel oscilloscope, the Range is {1|2}.

For four-channel oscilloscope, the Range is {1|2|3|4}.

Return format

The query returns the measurement result in character string.

Example

The query below returns the measurement value of the NDUTy of current channel.

:MEASure:NDUTy?

:MEASure:PWIDth?

Syntax

:MEASure[n]: PWIDth?

Description

Query the measurement value of the PWIDth of the current selected channel. Unit is Sec(s).

Parameter

Name	Type	Range	Default Value
[n]	Discrete	{1 2 3 4}	1

Explanation

Parameter[n] indicates channel, it can be ignored, and the default channel is the current selected one, The default value could be change.If [n] is replaced with a value, then the query returns measurement value of channel [n].

If no specified unit, then default unit will be Volt(v) for voltage. And default unit for time is Sec(s). Default unit for frequency is Hz. Default unit for percent is decimal form, for example 88% is 0.88.

For one-channel oscilloscope, the Range is { 1 }.

For two-channel oscilloscope, the Range is {1|2}.

For four-channel oscilloscope, the Range is {1|2|3|4}.

Return format

The query returns the measurement result in character string.

Example

The query below returns the measurement value of the PWIDth of current channel.

:MEASure:PWIDth?

:MEASure:NWIDth?

Syntax

:MEASure[n]: NWIDth?

Description

Query the measurement value of the NWIDth of the current selected channel. Unit is Sec(s).

Parameter

Name	Type	Range	Default Value
[n]	Discrete	{1 2 3 4}	1

Explanation

Parameter[n] indicates channel, it can be ignored, and the default channel is the current selected one, The default value could be change.If [n] is replaced with a value, then the query returns measurement value of channel [n].

If no specified unit, then default unit will be Volt(v) for voltage. And default unit for time is Sec(s). Default unit for frequency is Hz. Default unit for percent is decimal form, for example 88% is 0.88.

For one-channel oscilloscope, the Range is { 1 }.

For two-channel oscilloscope, the Range is {1|2}.

For four-channel oscilloscope, the Range is {1|2|3|4}.

Return format

The query returns the measurement result in character string.

Example

The query below returns the measurement value of the NWIDth of current channel.
:MEASure:NWIDth?

:MEASure:OVERshoot?

Syntax

:MEASure[n]: OVERshoot?

Description

Query the measurement value of the OVERshoot of the current selected channel.

Parameter

Name	Type	Range	Default Value
[n]	Discrete	{1 2 3 4}	1

Explanation

Parameter[n] indicates channel, it can be ignored, and the default channel is the current selected one, The default value could be change.If [n] is replaced with a value, then the query returns measurement value of channel [n].

If no specified unit, then default unit will be Volt(v) for voltage. And default unit for time is Sec(s). Default unit for frequency is Hz. Default unit for percent is decimal form, for example 88% is 0.88.

For one-channel oscilloscope, the Range is { 1 }.

For two-channel oscilloscope, the Range is {1|2}.

For four-channel oscilloscope, the Range is {1|2|3|4}.

Return format

The query returns the measurement result in character string.

Example

The query below returns the measurement value of the OVERshoot of current channel.
:MEASure:OVERshoot?

:MEASure:PREShoot?

Syntax

:MEASure[n]: PREShoot?

Description

Query the measurement value of the PREShoot of the current selected channel.

Parameter

Name	Type	Range	Default Value
[n]	Discrete	{1 2 3 4}	1

Explanation

Parameter[n] indicates channel, it can be ignored, and the default channel is the current selected one, The default value could be change.If [n] is replaced with a value, then the query returns measurement value of channel [n].

If no specified unit, then default unit will be Volt(v) for voltage. And default unit for time is Sec(s). Default unit for frequency is Hz. Default unit for percent is decimal form, for example 88% is 0.88.

For one-channel oscilloscope, the Range is { 1 }.

For two-channel oscilloscope, the Range is {1|2}.

For four-channel oscilloscope, the Range is {1|2|3|4}.

Return format

The query returns the measurement result in character string.

Example

The query below returns the measurement value of the PREShoot of current channel.
:MEASure:PREShoot?

:MEASure:RDElay?

Syntax

:MEASure[n]: RDElay?

Description

Query the measurement value of the RDElay of the current selected channel. Unit is Sec(s).

Parameter

Name	Type	Range	Default Value
[n]	Discrete	{1 2 3 4}	1

Explanation

When [n] is replaced with 1 or 2, this command measures rise delay time from channel 1 to channel 2. When [n] is replaced with 3 or 4, this command measures rise delay time from channel 3 to channel 4.

Parameter[n] indicates channel, it can be ignored, and the default channel is the current selected one, The default value could be change.If [n] is replaced with a value, then the query returns measurement value of channel [n].

If no specified unit, then default unit will be Volt(v) for voltage. And default unit for time is Sec(s). Default unit for frequency is Hz. Default unit for percent is decimal form, for example 88% is 0.88.

For one-channel oscilloscope, the Range is { 1 }.

For two-channel oscilloscope, the Range is {1|2}.

For four-channel oscilloscope, the Range is {1|2|3|4}.

Return format

The query returns the measurement result in character string.

Example

The query below returns the measurement value of the RDElay of current channel.

:MEASure:RDElay?

:MEASure:FDElay?

Syntax

:MEASure[n]: FDElay?

Description

Query the measurement value of the FDElay of the current selected channel. Unit is Sec(s).

Parameter

Name	Type	Range	Default Value
[n]	Discrete	{1 2 3 4}	1

Explanation

When [n] is replaced with 1 or 2, this command measures fall delay time from channel 1 to channel 2. When [n] is replaced with 3 or 4, this command measures fall delay time from channel 3 to channel 4.

Parameter[n] indicates channel, it can be ignored, and the default channel is the current selected one, The default value could be change.If [n] is replaced with a value, then the query returns measurement value of channel [n].

If no specified unit, then default unit will be Volt(v) for voltage. And default unit for time is Sec(s). Default unit for frequency is Hz. Default unit for percent is decimal form, for example 88% is 0.88.

For one-channel oscilloscope, the Range is { 1 }.

For two-channel oscilloscope, the Range is {1|2}.

For four-channel oscilloscope, the Range is {1|2|3|4}.

Return format

The query returns the measurement result in character string.

Example

The query below returns the measurement value of the FDElay of current channel.
:MEASure:FDElay?

:MEASure:RECVamp?

Syntax

:MEASure[n]: RECVAMP?

Description

Query the measurement value Vamp of square waveform.

Return format

The query returns the measurement amplitude as pixels in character string.

Example

The query below returns the measurement value Vamp of square waveform.
:MEASure:RECVAMP?

:ACQuire Command Subsystem

:ACQuire:TYPE

Syntax

:ACQuire:TYPE <type>

:ACQuire:TYPE?

Description

Set the acquisition mode of the oscilloscope.

Parameter

Name	Type	Range	Default Value
<type>	Discrete	{SAMPle AVERage PEAK }	SAMP

Explanation

When "AVERage" is selected, use the :ACQuire:AVERage<count> command to set the number of averages.

Return format

The query returns "SAMPLE", "AVERage" or "PEAK".

Example

The command below selects the average acquisition mode.

:ACQuire:TYPE AVERage

The query below returns "AVERage".

:ACQuire:TYPE?

:ACQuire:AVERage <count>

Syntax

:ACQuire:AVERage <count>

:ACQuire:AVERage?

Description

Set the number of averages.

Parameter

Name	Type	Range	Default Value
<count>	integer	{1~128}	4

Explanation

At present, the number of averages can be set is integer ranges from 1~ 128.

Return format

The query returns the number of average in character string.

Example

The command below sets the number of averages to "64".

:ACQuire:AVERage 64

The query below returns "64" :

:ACQuire:AVERage?

:ACQuire:MDEPth <mdep>

Syntax

:ACQuire:MDEPth <mdep>

:ACQuire:MDEPth?

Description

Set the number of waveform points that the oscilloscope can store in a single trigger sample.

Parameter

Name	Type	Range	Default Value
<mdep>	Discrete	{1K 10K 100K 1M 5M or 10M}	10K

Return format

The query returns the actual number of points (integer).

Example

The command below sets the memory depth to "10K ".

:ACQuire:MDEPth 10K

The query below returns the actual number of points, for example "10K ".

:ACQuire:MDEPth?

:TIMebase Command Subsystem

:TIMebase:SCALe

Syntax

:TIMebase:SCALe <scale_value>

:TIMebase:SCALe?

Description

Set the scale of the main time base.

Parameter

Name	Type	Range	Default Value
<scale_value>	Discrete	Please refer to Explanation	----

Explanation : Default to set the main time base.

VDS2062、VDS2064、VDS1022 time base gear

{5ns | 10ns | 20ns | 50ns | 100ns | 200ns | 500ns | 1us | 2us | 5us | 10us | 20us |
50us | 100us | 200us | 500us | 1ms | 2ms | 5ms | 10ms | 20ms | 50ms | 100ms | 200ms |
500ms | 1s | 2s | 5s | 10s | 20s | 50s | 100s}

VDS3102、VDS3104 time base gear

{2ns | 5ns | 10ns | 20ns | 50ns | 100ns | 200ns | 500ns | 1us | 2us | 5us | 10us
| 20us | 50us | 100us | 200us | 500us | 1ms | 2ms | 5ms | 10ms | 20ms | 50ms | 100ms
| 200ms | 500ms | 1s | 2s | 5s | 10s | 20s | 50s | 100s}

Return format

The query returns the horizontal scale in character string.

Example

The command below sets the horizontal scale of channel 1 to 200us/div.

:TIMebase:SCALe 200us

The query below returns "200us".

:TIMebase:SCALe?

:TIMEbase:HOFFset

Syntax

:TIMEbase:HOFFset <value>
:TIMEbase:HOFFset?

Description

Set the Horizontal offset of the time base.

Parameter

Name	Type	Range	Default Value
<value>	Integer	From -500 to +500000 (horizontal offset pixels)	0

Return Format

The query returns the offset in character string.

Explanation

Each div consists of 50 pixels along the horizontal direction. If the current main time base is 500us/div, and suppose the horizontal offset pixels are 100(that is 2div), then the horizontal offset time is 1.000ms. When timebase under slow mode, this command is invalid, it is only available when timebase under non-slow mode.

Example

The command below sets the horizontal offset of channel1 to 50.

:TIMEbase:HOFFset 50

The query returns horizontal offset pixels.

:TIMEbase:HOFFset?

:FFT Command Subsystem

:FFT:DISPlay <bool>

Syntax

:FFT:DISPlay <bool>
:FFT:DISPlay?

Description

Turn the display of FFT on or off.

Parameter

Name	Type	Range	Default Value
<bool >	Bool	{ OFF ON }	OFF

Return Format

The query returns “ON” or “OFF” .

Example

The command below turns the display of FFT on.

:FFT:DISPlay ON

The query returns “OFF”。
:FFT:DISPlay?

:FFT: FREQbase<hz>

Syntax

:FFT: FREQbase< hz >
:FFT: FREQbase?

Description

Set the center frequency of the FFT spectrum.

Parameter

Name	Type	Range	Default Value
< hz >	Discret	Please Refer to Explanation	-----

Explanation :

VDS2062、VDS2064 FFT center frequency

{0.05Hz | 0.1Hz | 0.25Hz | 0.5Hz | 1Hz | 2.5Hz | 5Hz | 10Hz | 25Hz | 50Hz
| 100Hz | 250Hz | 500Hz | 1KHz | 2.5KHz | 5KHz | 10KHz | 25KHz | 50KHz
| 125KHz | 250KHz | 500KHz | 1.25KHz | 2.5KHz | 5MHz | 12.5MHz | 25MHz
| 50MHz | 100MHz | 200MHz | 400MHz | 800MHz }

VDS3102、VDS3104 FFT center frequency

{0.05Hz | 0.1Hz | 0.25Hz | 0.5Hz | 1Hz | 2.5Hz | 5Hz | 10Hz | 25Hz | 50Hz
| 100Hz | 250Hz | 500Hz | 1KHz | 2.5KHz | 5KHz | 10KHz | 25KHz | 50KHz
| 125KHz | 250KHz | 500KHz | 1.25KHz | 2.5KHz | 5MHz | 12.5MHz | 25MHz
| 50MHz | 100MHz | 200MHz | 400MHz | 800MHz | 1.6GHz }

VDS1022 FFT center frequency

{0.125Hz | 0.25Hz | 0.625Hz | 1.25Hz | 2.5Hz | 6.25Hz | 12.5Hz | 25Hz | 50Hz
| 62.5Hz | 125Hz | 250Hz | 625Hz | 1.25KHz | 2.5KHz | 6.25KHz | 12.5KHz | 25KHz | 62.5KHz |
125KHz | 250KHz | 625KHz | 1.25MHz | 2.5MHz | 5MHz }

Return format

The query returns the frequency value in character string.

Example

The command below sets the center frequency of the FFT spectrum to 10 MHz.

:FFT: FREQbase 10MHz

The query returns “10MHz”.

:FFT: FREQbase?

:FFT:SOURce <source>

Syntax

:FFT:SOURce <source>

:FFT:SOURce?

Description

Select the signal source of FFT operation.

Parameter

Name	Type	Range	Default Value
<source >	Discret	{CH1 CH2 CH3 CH4}	CH1

Explanation

For one-channel oscilloscope, the Range is { 1 }.

For two-channel oscilloscope, the Range is {1|2}.

For four-channel oscilloscope, the Range is {1|2|3|4}.

Return Format

The query returns "CH1", "CH2", "CH3" or "CH4".

Example

The command below selects channel 1 as the signal source.

:FFT:SOURce CH1

The query below returns "CH1".

:FFT:SOURce?

:FFT:FORMat VRMS <vrms_scale>

Syntax

:FFT:FORMat VRMS <vrms_scale>

:FFT:FORMat?

Description

Set the VRMS scale of FFT.

Parameter

Name	Type	Range	Default Value
< vrms_scale >	Discrete	{2mv 5mv 10mv 20mv 50mv 100mv 200mv 500mv 1v 2v 5v 10v}	---

Description

Parameter should be numeric without unit, default unit for voltage is V.

Return format

The query returns VRMS or DB.

Example

The command below select VRMS as FFT format, and set VRMS scale to 0.5V, ie. 500mV

```
:FFT:FORMat VRMS 0.5
```

The query below returns VRMS.

```
:FFT:FORMat?
```

:FFT:FORMat DB <dB_scale>

Syntax

```
:FFT:FORMat DB <dB_scale>
```

```
:FFT:FORMat?
```

Description

Set the DB scale of FFT.

Parameter

Name	Type	Range	Default Value
< dB_scale>	Discret	{1DB 2DB 5DB 10DB 20DB}	-----

Explanation

The query returns DB.

Return format

The command below select DB as FFT format, and set 2DB.

```
:FFT:FORMat DB 2DB
```

The query returns DB.

```
:FFT:FORMat?
```

:FFT:WINDow <item>

Syntax

```
:FFT:WINDow <item>
```

```
:FFT:WINDow?
```

Description

Select the window function of FFT operation.

Parameter

Name	Type	Range	Default Value
< item >	Discrete	{RECTangle HANNing HAMMing BLACkman}	RECTangle

Return Format

The query returns "RECT", "HANN", "HAMM" or "BLAC".

Example

The command below selects RECTangle.

:FFT:WINDow RECTangle

The query returns " RECTangle".

:FFT:WINDow?

:FFT:ZONE <factor>

Syntax

:FFT:ZONE <factor>

:FFT:ZONE?

Description

Select the scaling of FFT operation.

Parameter

Name	Type	Range	Default Value
< factor >	Discrete	{X1 X2 X5 X10}	X1

Return Format

The query returns X1、X2、X5 or X10.

Example

The command below sets "X5" as the scaling.

:FFT:ZONE X5

The query returns "X5" .

:FFT:ZONE?

:CHANnel Command Subsystem

:CHANnel:DISPlay

Syntax

:CHANnel<n>:DISPlay <bool>

:CHANnel<n>:DISPlay?

Description

Turn the display of the channel on or off.

Parameter

Name	Type	Range	Default Value
<n>	Discrete	{1 2 3 4}	1
<bool>	Bool	{OFF ON}	OFF

Explanation

For one-channel oscilloscope, the range is {1}.

For two-channel oscilloscope, the range is {1|2}.

For four-channel oscilloscope, the range is {1|2|3|4}.

Return Format

The query returns "OFF" or "ON".

Example

The command below turns the display of channel1 on.

:CHANnel1:DISPlay ON

The query returns "ON".

:CHANnel1:DISPlay?

:CHANnel:COUPling

Syntax

:CHANnel<n>:COUPling <coupling>

:CHANnel<n>:COUPling?

Description

Set the coupling mode of the channel to "AC", "DC" or "GND".

Parameter

Name	Type	Range	Default Value
<n>	Discrete	{1 2 3 4}	1
<coupling>	Discrete	{AC DC GND}	DC

Explanation

For one-channel oscilloscope, the range is {1}.

For two-channel oscilloscope, the range is {1|2}.

For four-channel oscilloscope, the range is {1|2|3|4}.

Return Format

The query returns "AC", "DC" or "GND".

Example

The command below sets the input coupling mode of channel 1 to "DC".

:CHANnel1:COUPling DC

The query returns "DC".

:CHANnel1:COUPling?

:CHANnel:PROBe

Syntax

:CHANnel<n>:PROBe <atten>

:CHANnel<n>:PROBe?

Description

Set the attenuation ratio of the probe.

Parameter

Name	Type	Range	Default Value
<n>	Discrete	{1 2 3 4}	1
<atten>	Discrete	{X1 X10 X100 X1000}	X10

Explanation

For one-channel oscilloscope, the range is {1}.

For two-channel oscilloscope, the range is {1|2}.

For four-channel oscilloscope, the range is {1|2|3|4}.

Return Format

The query returns "X1", "X10", "X100" or "X1000".

Example

The command below sets the attenuation ratio of the probe connected to channel1 to 10.

:CHANnel1:PROBe X10

The query returns "X10".

:CHANnel1:PROBe?

:CHANnel:SCALE

Syntax

:CHANnel<n>:SCALE <scale>

:CHANnel<n>:SCALE?

Description

Set the vertical scale of the specified waveform display.

Parameter

Name	Type	Range	Default Value
<n>	Discrete	{1 2 3 4}	1
<scale>	Discrete	Please refer to Explanation	----

Explanation

For one-channel oscilloscope, the range is {1}.

For two-channel oscilloscope, the range is {1|2}.

For four-channel oscilloscope, the range is {1|2|3|4}.

Scale range under probe rate X1

VDS2062 VDS1022 and VDS2064:

{5mv|10mv|20m v|50mv|100mv|200m v|500mv|1v|2v|5v}

VDS3102 and VDS3104:

{2mv|5mv|10mv|20m v|50mv|100mv|200m v|500mv|1v|2v|5v}

Scale range under probe rate besides X1

The value should be adjusted according to probe rate, each scale value multiply the probe rate results in the real scale value. For example, 500mv/div at X1 rate, 5v/div at X10 rate, 50v/div at X100 rate, 500v/div at X1000 rate.

Return Format

The query returns the vertical scale in character string.

Example

The command below sets the vertical scale of channel 1 to 500mV/div.

The default unit for voltage is volt(v).

:CHANnel1:SCALE 0.5

The query returns "0.5" .

:CHANnel1:SCALE?

:CHANnel:OFFSet

Syntax

:CHANnel<n>:OFFSet <offset>

:CHANnel<n>:OFFSet?

Description

Set the vertical offset of the specified waveform display.

Parameter

Name	Type	Range	Default Value
<n>	Discrete	{1 2 3 4}	1
<offset>	Integer	From -250 to 250 (pixels)	0

Explanation

Each div consists of 25 pixels,if vertical offset is 20,then it means $20/25 = 0.8\text{div}$

Return Format

The query returns the offset value in character string.

Example

The command below sets the vertical offset of channel 1 to 25 pixels, one div is 25 pixels.

:CHANnel1:OFFSet 25

The query below returns 25pixels.

:CHANnel1:OFFSet?

:CHANnel:HARDfreq?

Syntax

:CHANnel[n]: HARDfreq?

Description

To query hardware frequency value of specified channel.

Return format

The query returns the frequency value in character string.

Example

The query below returns hardware frequency value of channel 1.

:CHANnel1: HARDfreq?

:CHANnel:INVerse

Syntax

:CHANnel[n]: INVerse <bool>

:CHANnel[n]: INVerse?

Description

Query or set waveform inverse of specified channel.

Return format

Name	Type	Range	Default Value
[n]	Discrete	{1 2 3 4}	1
<bool>	Bool	{OFF ON}	OFF

Description

For one-channel oscilloscope, the range is {1}.

For two-channel oscilloscope, the range is {1|2}.

For four-channel oscilloscope, the range is {1|2|3|4}.

Return format

The query returns "OFF" or "ON" .

Example

The command below turns on waveform inverse of channel 1.

:CHANnel1: INVerse ON

The query below returns "ON" .

:CHANnel1: INVerse?

:LAN Command Subsystem

:LAN:IPADdress

Syntax

:LAN:IPADdress <string>
:LAN:IPADdress?

Description

Set the IP address of the instrument.

Parameter

Name	Type	Range	Default Value
<string>	ASCIICharacter String	nnn,nnn,nnn,nnn	0,0,0,0

Explanation

When setting the <string>, the range of the first nnn is from 0 to 223 (except 127) and the ranges of the other three nnn are from 0 to 255.

Return Format

The query returns the current IP address in character string.

Example

The command below sets the IP address to: 192.168.1.80。

:LAN:IPADdress 192.168.1.80

The query returns "192.168.1.80"。

:LAN:IPADdress?

:LAN:PORT

Syntax

:LAN:PORT <value>
:LAN:PORT?

Description

Distribute a port for the instrument.

Parameter

Name	Type	Range	Default Value
<value>	Integer	1 ~3000	3000

Explanation

When setting the <value>, the range of the port is from 1 to 3000.

Return Format

The query returns the current port value in character string.

Example

The command below sets the port value to:3000。

:LAN:PORT 3000

The query returns "3000" 。

:LAN:PORT?

:LAN:GATeway

Syntax

:LAN:GATeway <string>
:LAN:GATeway?

Description

Distribute a gateway for the instrument.

Parameter

Name	Type	Range	Default Value
<string>	ASCIICharacter String	nnn,nnn,nnn,nnn	0,0,0,0

Explanation

When setting the <string>, the range of the first nnn is from 0 to 223 (except 127) and the ranges of the other three nnn are from 0 to 255.

Return Format

The query returns the current gateway in character string.

Example

The command below sets the gateway to:192.168.1.1。

:LAN:GATeway 192.168.1.1

The query returns “192.168.1.1” 。

:LAN:GATeway?

:LAN:SMASk

Syntax

:LAN:SMASk <string>
:LAN:SMASk?

Description

Distribute a subnet mask for the instrument.

Parameter

Name	Type	Range	Default Value
<string>	ASCIICharacter String	nnn,nnn,nnn,nnn	0,0,0,0

Explanation

When setting the <string>, the range of each nnn is from 0 to 255.

Return Format

The query returns the current subnet mask in character string.

Example

The command below sets the subnet mask to: 255.255.255.0.

:LAN:SMASk 255,255,255,0

The query returns “255.255.255.0” 。

:LAN:SMASk?

:LAN:REStart

Syntax

:LAN:REStart <switch>

Description

Restart the oscilloscope.

Parameter

Name	Type	Range	Default Value
<switch>	Discrete	{ON OFF}	OFF

Explanation

After setting net parameters, send ":LAN:REStart ON" and close the SCPI interface. After automatic restart, enter SCPI again. By query, the new net parameters would be those you set.

:TRIGger Command Subsystem

:TRIGger:TYPE <type>

Syntax

:TRIGger:TYPE <type>
:TRIGger:TYPE?

Description

Select the trigger type.

Parameter

Name	Type	Range	Default Value
<type>	Discrete	{SINGle ALTErnate}	SING

Return Format

The query returns the current trigger type.

Example

The command below selects slope trigger.
:TRIGger:TYPE SINGle
The query below returns "SINGle".
:TRIGger:TYPE?

:TRIGger:MODE <mode>

Syntax

:TRIGger:MODE <mode>
:TRIGger:MODE?

Description

Select the trigger mode.

Parameter

Name	Type	Range	Default Value
<mode>	Discrete	{AUTO NORMal SINGle}	AUTO

Return Format

The query returns the current trigger mode. When ALT, the trigger mode can only be AUTO.

Example

The command below selects normal as trigger mode.

```
:TRIGger:MODE NORMAl
```

The query below returns "NORMAl".

```
:TRIGger:MODE?
```

:TRIGger:SINGle <Smode>**Syntax**

```
:TRIGger:SINGle <Smode>
```

```
:TRIGger:SINGle?
```

Description

Select the trigger type edge or video under single trigger.

Parameter

Name	Type	Range	Default Value
<Smode>	Discrete	{EDGE VIDeo }	EDGE

Return Format

The query returns "EDGE" or "VIDeo".

Example

The command below selects "VIDeo" as trigger type under single trigger.

```
:TRIGger:SINGle VIDeo
```

The query below returns "VIDeo".

```
:TRIGger:SINGle?
```

:TRIGger:ALT <Amode>**Syntax**

```
:TRIGger:ALT <mode>
```

```
:TRIGger:ALT?
```

Description

Select the trigger type edge or video under ALT trigger.

Parameter

Name	Type	Range	Default Value
<Amode>	Discrete	{EDGE VIDeo }	EDGE

Return Format

The query returns "EDGE" or "VIDeo".

Example

The command below selects "VIDeo" as trigger type under ALT trigger.

```
:TRIGger:ALT VIDeo
```


The query below returns "VIDeo".
:TRIGger:ALT?

:TRIGger:SINGle:EDGE

:TRIGger:SINGle:EDGE:SOURce

Syntax

:TRIGger:SINGle:EDGE:SOURce <source>

:TRIGger:SINGle:EDGE:SOURce?

Description

Select the source under SINGLE EDGE trigger.

Parameter

Name	Type	Range	Default Value
<source>	Discrete	{CH1 CH2 CH3 CH4 }	CH1

Return Format

For one-channel oscilloscope, the query returns "CH1" .

For two-channel oscilloscope, the query returns "CH1" or "CH2" .

For four-channel oscilloscope, the query returns "CH1" , "CH2" , "CH3" or "CH4" .

Example

The command below selects "CH2" as the source under SINGLE EDGE trigger.

:TRIGger:SINGle:EDGE:SOURce CH2

The query below returns "CH2".

:TRIGger:SINGle:EDGE:SOURce?

:TRIGger:SINGle:EDGE:SLOPe

Syntax

:TRIGger:SINGle:EDGE:SLOPe <slope>

:TRIGger:SINGle:EDGE:SLOPe?

Description

Select the slope under SINGLE EDGE trigger.

Parameter

Name	Type	Range	Default Value
<slope>	Discrete	{RISE FALL}	RISE

Return Format

The query returns "RISE " or "FALL".

Example

The command below selects "FALL" as the slope under SINGLE EDGE trigger.

:TRIGger:SINGle:EDGE:SLOPe FALL

The query below returns "FALL".

:TRIGger:SINGle:EDGE:SLOPe?

:TRIGger:SINGle:EDGE:LEVel

Syntax

:TRIGger:SINGle:EDGE:LEVel <level>
:TRIGger:SINGle:EDGE:LEVel?

Description

Set the trigger level under SINGLE EDGE trigger. And the unit is in accordance with the current unit of the voltage.

Parameter

Name	Type	Range	Default Value
<level>	Integer (pixel number)	from (-6div - zero position) ×25 to (6div - zero position) ×25 (25 is pixels/div)	0

Explanation

Each div consists of 25 pixels along the vertical direction. If the query returns "20" for trigger level, which means 0.8div, and if the vertical scale is 1v/div, then the trigger level would be 0.8v, that is 800mv.

Here are the calculation steps.

20pixels / 25pixels = 0.8div
0.8div * 1v/div = 0.8v

Return Format

The query returns the pixels number of the trigger level in character string.

Example

The command below sets "25" as the trigger level under SINGLE EDGE trigger.

:TRIGger:SINGle:EDGE:LEVel 25
The query returns "25".
:TRIGger:SINGle:EDGE:LEVel?

:TRIGger:SINGle:VIDeo

:TRIGger:SINGle:VIDeo:SOURce

Syntax

:TRIGger:SINGle:VIDeo:SOURce <source>
:TRIGger:SINGle:VIDeo:SOURce?

Description

Select the source under SINGLE VIDEO trigger.

Parameter

Name	Type	Range	Default Value
<source>	Discrete	{CH1 CH2 CH3 CH4 }	CH1

Return Format

For one-channel oscilloscope, the query returns "CH1" .

For two-channel oscilloscope, the query returns "CH1" or " CH2" .

For four-channel oscilloscope, the query returns "CH1" , " CH2" , "CH3" or "CH4" .

Example

The command below selects "CH2" as the source under SINGLE VIDEO trigger.

:TRIGger:SINGle:VIDeo:SOURce CH2

The query below returns "CH2" .

:TRIGger:SINGle:VIDeo:SOURce?

:TRIGger:SINGle:VIDeo:MODU

Syntax

:TRIGger:SINGle:VIDeo:MODU <standard>
:TRIGger:SINGle:VIDeo:MODU?

Description

Select video standard under SINGLE VIDEO trigger.

Parameter

Name	Type	Range	Default Value
<standard>	Discrete	{PAL SECam NTSC}	NTSC

Return Format

The query returns "PAL", "SECam" or "NTSC".

Example

The command below select "NTSC" as the video standard under SINGLE VIDEO trigger.

:TRIGger:SINGle:VIDeo:MODU NTSC

The query below returns "NTSC" .

:TRIGger:SINGle:VIDeo:MODU?

:TRIGger:SINGle:VIDeo:SYNC

Syntax

:TRIGger:SINGle:VIDeo:SYNC <mode>
:TRIGger:SINGle:VIDeo:SYNC?

Description

Select the Synchronization Type among LINE, FIELD, ODDField, EVENfield or LNUMber under SINGLE VIDEO trigger.

Parameter

Name	Type	Range	Default Value
<mode>	Discrete	{ LINE FIELD ODD EVEN LNUM}	LINE

Return Format

The query returns "LINE", "FIELD", "ODD", "EVEN" or "LNUM".

Example

The command below select "ODD" as the Synchronization Type under SINGLE VIDEO trigger.

```
:TRIGger:SINGle:VIDeo:SYNC ODD
```

The query below returns "ODD".

```
:TRIGger:SINGle:VIDeo:SYNC?
```

:TRIGger:SINGle:VIDeo:LNUM**Syntax**

```
:TRIGger:SINGle:VIDeo:LNUM<line>
```

```
:TRIGger:SINGle:VIDeo:LNUM?
```

Description

Set line number under SINGLE VIDEO trigger when the synchronization type is "LNUM".

Parameter

Name	Type	Range	Default Value
<line_num>	Integer	NTSC: from 1 to 525 PAL: from 1 to 625 SECam: from 1 to 625	1

Return Format

The query returns line number in character string under SINGLE VIDEO trigger. And the source defaults to the current source.

Example

The command below sets "100" as the Line number under SINGLE VIDEO trigger.

```
:TRIGger:SINGle:VIDeo:LNUM100
```

The query below returns "100".

```
:TRIGger:SINGle:VIDeo:LNUM?
```

:TRIGger:ALT:EDGE**:TRIGger:ALT:EDGE:SOURce**

Syntax

```
:TRIGger:ALT:EDGE:SOURce <source>
```

```
:TRIGger:ALT:EDGE:SOURce?
```

Description

Select the source under ALT EDGE trigger.

Parameter

Name	Type	Range	Default Value
<source>	Discrete	{CH1 CH2 CH3 CH4 }	CH1

Return Format

For one-channel oscilloscope, the query returns "CH1" .

For two-channel oscilloscope, the query returns "CH1" or "CH2" .

For four-channel oscilloscope, the query returns "CH1" , "CH2" , "CH3" or "CH4" .

Example

The command below selects "CH2" as the source under ALT EDGE trigger.

```
:TRIGger:SINGLE:EDGE:SOURce CH2
```

The query below returns "CH2".

```
:TRIGger:SINGLE:EDGE:SOURce?
```

:TRIGger:ALT:EDGE:SLOPe**Syntax**

```
:TRIGger:ALT:EDGE:SLOPe <slope>
```

```
:TRIGger:ALT:EDGE:SLOPe?
```

Description

Select the slope under ALT EDGE trigger.

Parameter

Name	Type	Range	Default Value
<slope>	Discrete	{RISE FALL}	RISE

Return Format

The query returns "RISE " or "FALL".

Example

The command below selects "FALL" as the slope under ALT EDGE trigger.

```
:TRIGger:ALT:EDGE:SLOPe FALL
```

The query below returns "FALL" .

```
:TRIGger:ALT:EDGE:SLOPe?
```

:TRIGger:ALT:EDGE:LEVel**Syntax**

:TRIGger:ALT:EDGE:LEVel <level>
:TRIGger:ALT:EDGE:LEVel?

Description

Set the trigger level under ALT EDGE trigger. And the unit is in accordance with the current unit of the voltage.

Parameter

Name	Type	Range	Default Value
<level>	Integer (pixel number)	from (-6div - zero position) ×25 to (6div - zero position) ×25 (25 is pixels/div)	0

Explanation

Each div consists of 25 pixels along the vertical direction. If the query returns "20" for trigger level, which means 0.8div, and if the vertical scale is 1v/div, then the trigger level would be 0.8v, that is 800mv.

Here are the calculation steps.
 $20\text{pixels} / 25\text{pixels} = 0.8\text{div}$
 $0.8\text{div} * 1\text{v/div} = 0.8\text{v}$

Return Format

The query returns the pixels number of the trigger level in character string.

Example

The command below sets "50" as the trigger level under ALT EDGE trigger.

:TRIGger:ALT:EDGE:LEVel 50
The query returns "50" .
:TRIGger:ALT:EDGE:LEVel?

:TRIGger:ALT:VIDeo

:TRIGger:ALT:VIDeo:SOURce

Syntax

:TRIGger:ALT:VIDeo:SOURce <source>
:TRIGger:ALT:VIDeo:SOURce?

Description

Select the source under ALT VIDEO trigger.

Parameter

Name	Type	Range	Default Value
<source>	Discrete	{ CH1 CH2 CH3 CH4 }	CH1

Return Format

For one-channel oscilloscope, the query returns "CH1" .

For two-channel oscilloscope, the query returns "CH1" or "CH2".
 For four-channel oscilloscope, the query returns "CH1", "CH2", "CH3" or "CH4".
 Video trigger under ALT mode, only one channel is available.

Example

The command below selects "CH2" as the source under ALT VIDEO trigger.
 :TRIGger:ALT:VIDeo:SOURce CH2
 The query below returns "CH2".
 :TRIGger:ALT:VIDeo:SOURce?

:TRIGger:ALT:VIDeo:MODU

Syntax

:TRIGger:ALT:VIDeo:MODU <standard>
 :TRIGger:ALT:VIDeo:MODU?

Description

Select video standard under ALT VIDEO trigger.

Parameter

Name	Type	Range	Default Value
<standard>	Discrete	{PAL SECam NTSC}	NTSC

Return Format

The query returns "PAL", "SECam" or "NTSC".

Example

The command below select "NTSC" as the video standard under ALT VIDEO trigger.
 :TRIGger:ALT:VIDeo:MODU NTSC
 The query below returns "NTSC".
 :TRIGger:ALT:VIDeo:MODU?

:TRIGger:ALT:VIDeo:SYNC

Syntax

:TRIGger:ALT:VIDeo:SYNC <mode>
 :TRIGger:ALT:VIDeo:SYNC?

Description

Select the Synchronization Type among LINE, FIELD, ODDfield, EVENfield or LNUMBER under ALT VIDEO trigger.

Parameter

Name	Type	Range	Default Value
<mode>	Discrete	{ LINE FIELD ODD EVEN LNUM }	LINE

Return Format

The query returns "LINE", "FIELD", "ODD", "EVEN" or "LNUM".

Example

The command below select "ODD" as the Synchronization Type under ALT VIDEO trigger.
 :TRIGger:ALT:VIDeo:SYNC ODD
 The query below returns "ODD".
 :TRIGger:ALT:VIDeo:SYNC?

:TRIGger:ALT:VIDeo:LNUM

Syntax

:TRIGger:ALT:VIDeo:LNUM<line>

:TRIGger:ALT:VIDeo:LNUM?

Description

Set line number under ALT VIDEO trigger and the synchronization type is "LNUM".

Parameter

Name	Type	Range	Default Value
<line>	Integer	NTSC: from 1 to 525 PAL: from 1 to 625 SECam: from 1 to 625	1

Return Format

The query returns line number in character string under ALT VIDEO trigger. And the source defaults to the current source.

Example

The command below sets "100" as the Line number under ALT VIDEO trigger.

:TRIGger:ALT:VIDeo:LNUM100

The query below returns "100".

:TRIGger:ALT:VIDeo:LNUM?